



bytes**at**work

# DataSheet

---

Rev. 1.0      15.08.2025



industrial development kit

byteDEVKIT OSM-S



## Copyright Notice

Copyright 2025 bytes at work AG, CH-8406 Winterthur, Switzerland. All rights reserved.

**Reproduction** in any form or by any means without permission is prohibited. Bytes at work AG reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the company. Information provided in this manual is intended to be accurate and reliable. However, bytes at work assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, bytes at work assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein. bytes at work reserves the right to make changes in the product design without notice to its users.

## Trademarks

Product names, logos, brands, and other trademarks featured, or referred to are the property of their respective trademark holders. These include, but are not limited to U-Boot, Linux and ARM.

## Disclaimer

**Bytesatwork** does not guarantee that the information in this manual is up-to-date, correct, complete or of good quality. Nor does bytesatwork assume guarantee for further usage of the information. Liability claims against bytesatwork, referring to material or non-material related damages caused, due to usage or non-usage of the information given in the manual, or due to usage of erroneous or incomplete information, are exempted, as long as there is no bytesatwork.

**Bytesatwork** explicitly reserves the rights to change or add to the contents of this manual or parts of it without special notification.

## Imprint

Bytesatwork  
Technoparkstrasse 7  
CH-8406 Winterthur  
+41 52 213 79 79

info@bytesatwork.ch  
www.bytesatwork.io

## Symbols and Typographic Conventions

These symbols represent important details or aspects for working with bytesatwork-products.



### NOTICE

Follow instructions. Acting against the procedure described can lead to malfunction.



[www.bytesatwork.io](http://www.bytesatwork.io)

# Table of Contents

|                                                    |           |
|----------------------------------------------------|-----------|
| <b>1. Revision History</b>                         | <b>4</b>  |
| <b>2. Overview</b>                                 | <b>4</b>  |
| 2.1. General Information                           | 5         |
| 2.2. Technical Data byteDEVKIT OSM-S               | 6         |
| 2.3. Technical Data of the SOM byteENGINE IMX9x    | 7         |
| 2.4. Technical Data of the SOM byteENGINE STM32MP2 | 8         |
| 2.5. Decision guidance byteDEVKIT OSM-S            | 9         |
| 2.6. Quickstart guide                              | 10        |
| 2.7. Yocto Project Quick Build                     | 11        |
| <b>3. Pinout functions</b>                         | <b>12</b> |
| 3.1. X4 MIPI DSI connector                         | 12        |
| 3.2. X5 MIPI Touch Connector                       | 13        |
| 3.3. X6 5-inch LVDS Display Connector              | 13        |
| 3.4. X7 LVDS Touch connector                       | 14        |
| 3.5. X3 Camera                                     | 15        |
| 3.6. X12 60PIN Connector                           | 16        |
| <b>4. Connectors</b>                               | <b>19</b> |
| <b>5. Boot modes</b>                               | <b>20</b> |
| 5.1. byteENGINE IMX9x                              | 20        |
| 5.2. byteENGINE STM32MP2                           | 21        |
| <b>6. Mechanical dimensions byteDEVKIT OSM-S</b>   | <b>22</b> |
| 6.1. Mechanical dimensions of byteENGINE IMX9x     | 23        |
| 6.2. Mechanical dimensions of byteENGINE STM32MP2  | 23        |
| <b>7. Ordering info</b>                            | <b>24</b> |
| <b>8. References byteDEVKIT OSM-S</b>              | <b>25</b> |


# 1. Revision History

| Hardware Revision | Marking on PCB       | Release Date | Info                              |
|-------------------|----------------------|--------------|-----------------------------------|
| 1.0               | byteDEVKIT OSM-S 1.0 | 2025         | First version available for sales |
| 0.1               | byteDEVKI OSM-S 0.1  | 2024         | Prototypes                        |

**NOTICE**

This document refers to byteDEVKIT OSM-S 1.0

# 2. Overview



## 2.1. General Information

### Maximum flexibility and simplicity

The byteDEVKIT OSM-S enables you to work on your own projects while shortening time-to-market significantly. It is engineered for a huge variety of applications and the flexible structure allows easy implementations of even profound changes. Furthermore, it offers maximum flexibility and simplicity. The byteDEVKIT OSM-S is available with the complete i.MX9-Module family and the STM32MP2x Module family:

- > IMX9131, IMX9121,
- > IMX9352, IMX9351, IMX9332, IMX9331, IMX9301
- > STM32MP251, STM32MP253,
- > STM32MP255, STM32MP257.

### Plenty of possibilities

The byteDEVKIT OSM-S includes the base board that features a strong array of interfaces for a variety of applications:

- > 2x 1000Mbit Ethernet RJ45
- > 1x microSD Slot
- > 1x USB Host Type A
- > 1x USB OTG microUSB
- > 5-inch LVDS Touchscreen Display
- > 5-inch MIPI DSI Touchscreen Display
- > 1x 60 PIN Header: Extension-Header X12: GPIO, SAI1, SPI7, CAN1, CAN2, PWM, ADC, UART2, UART3, UART5, UART8, I2C1, I2C2, SD3
- > Boot mode switches
- > CSI Camera 4lanes

### Ready to start and use

The byteDEVKIT OSM-S package comes ready to run, which includes a power supply, a serial console and a microSD card with pre-installed embedded Linux. As a result, you benefit from rapid prototyping, maximum flexibility and a very short time-to-market.

### Low consumption & high performance

The NXP i.MX9 processors and the ST STM32MP2 CPUs are on the cutting edge of their industry thanks to the combination of functional integration, high performance and extremely low power consumption.

### Two in one

The byteENGINE IMX9x has up to two Cortex®-A55 cores for exceptionally high system performance. The Cortex®-M33 core enables real-time applications with low performance at the same time.

Similarly, the byteENGINE STM32MP2 has up to two Cortex®-A35 cores and a Cortex®-M33 core for real-time applications with low performance.

Both byteENGINEs include a NPU and advanced security features.

### Easy to adapt to your project

Thanks to the 60PIN header, rapid prototyping is easy and efficient. The byteDEVKIT OSM-S offers a variety of interfaces such as I2C, SPI - CAN, UART, USART, PWM and GPIO.

### Quality which endures

Our Swiss standard pays off. We only install components to the byteDEVKIT OSM-S that will be still available in ten years. The byteDEVKIT OSM-S is engineered with the focus on robustness and longevity.

## 2.2. Technical Data byteDEVKIT OSM-S

### byteDEVKIT OSM-S

|                         |                                                                              |
|-------------------------|------------------------------------------------------------------------------|
| <b>Connectors</b>       | 2x 1000MBit Ethernet RJ45                                                    |
| <b>Hardware Slot</b>    | 1x microSD slot                                                              |
| <b>Device Slot 1</b>    | 1x USB 3.0 Host Type A                                                       |
| <b>Device Slot 2</b>    | 1x USB OTG microUSB                                                          |
| <b>Display</b>          | 5-inch LVDS Display with Touch<br>or ;<br>5-inch MIPI DSI Display with Touch |
| <b>Connector 60 PIN</b> | X12: GPIO, SAI1, SPI7, CAN1, CAN2, PWM, ADC                                  |

## 2.3. Technical Data of the SOM byteENGINE IMX9x



### Notice

For detailed information regarding the i.MX9x please refer to the document byteENGINE IMX9x Datasheet.



[Datasheet byteENGINE IMX9x](#)

### byteENGINE IMX9x Specification

|                     |                                                  |
|---------------------|--------------------------------------------------|
| <b>CPU</b>          | Up to Dual ARM® Cortex® A55 processors 1.7 GHz   |
| <b>Co-Processor</b> | Cortex® M33 up to 250 MHz                        |
| <b>Memory</b>       | 512 MB to 2048 MB LPDDR4                         |
| <b>Flash eMMC</b>   | up to 128 GB                                     |
| <b>Temperature</b>  | Industrial: -40° to +85° C, consumer: 0 to 85° C |
| <b>Power Supply</b> | 5.0 V, 4 W                                       |
| <b>Dimensions</b>   | 30 x 30 x 3 mm                                   |

## 2.4. Technical Data of the SOM byteENGINE STM32MP2



### Notice

For detailed information regarding the STM32MP2 please refer to the document byteENGINE STM32MP2 Datasheet.



[Datasheet byteENGINE STM32MP2](#)

### byteENGINE STM32MP2 Specification

|                     |                                                  |
|---------------------|--------------------------------------------------|
| <b>CPU</b>          | Up to Dual ARM® Cortex® A35 processors 1.5 GHz   |
| <b>Co-Processor</b> | Cortex® M33 up to 400 MHz                        |
| <b>Memory</b>       | 512 MB to 2048 MB LPDDR4                         |
| <b>Flash eMMC</b>   | up to 128 GB                                     |
| <b>Temperature</b>  | Industrial: -40° to +85° C, consumer: 0 to 85° C |
| <b>Power Supply</b> | 5.0 V, 4 W                                       |
| <b>Dimensions</b>   | 30 x 30 x 3 mm                                   |



## 2.5. Decision guidance byteDEVKIT OSM-S

The following six steps help identifying the suitable DEVKIT with the needed SOM for the specific customer application.

> **Step 1:** Select the needed CPU for the SOM

> **Choose Options as described in the Datasheets**

**STM32MP2**

**IMX9x**

[Datasheet byteENGINE IMX9x](#)

[Datasheet byteENGINE STM32MP2](#)

> **Step 2:** Select the needed CPU speed

**STM32MP2**

**IMX9x**

1.2 GHz / 1.5 GHz

800 MHz / 900 MHz / 1.4 GHz / 1.7 GHz

> **Step 2:** Select the needed flash memory capacity

> **Choose eMMC 8 / 16 / 32 / 64 GB / 128 GB**

> **Step 3:** Select the needed RAM capacity

> **Choose 512 / 1024 / 1536 / 2048 MB**

> **Step 4:** Select the needed temperature range

> **Choose consumer or industrial**

> **Step 5:** Select the needed Display

> **Choose 5-inch LVDS with Touch / 5-inch MIPI DSI with Touch / without**



[Ordering info](#)

## 2.6. Quickstart guide

The Quickstart guide simplifies the startup process with step-by-step instructions. Should you have questions you are always welcome to ask our experts for technical support. See Chapter „[Connectors](#)“ for connectors layout.

- > **Step 1:** Connect the USB-RS232 cable to SL1 (black wire is marking PIN 1)
- > **Step 2:** (Optional) Connect the network cable
- > **Step 3:** Put a valid micro SD-Card into the SD-Card slot
- > **Step 4:** Connect the console cable to your computer serial or USB port if you're using the adapter.

> Start the Terminal Software and configure your serial port with the following port settings:

### Port Settings

|                 |        |
|-----------------|--------|
| Bits per second | 115200 |
| Data bits       | 8      |
| Parity          | N      |
| Stop bits       | 1      |

- > **Step 5:** Connect the power supply to X13
- > **Step 6:** After connected to power supply, the console shows the boot log
- > **Step 7:** Login to the system with:

### Login Data

|          |        |
|----------|--------|
| User     | root   |
| Password | rootme |

## 2.7. Yocto Project Quick Build

These steps guide you through the process for an image build using the Yocto Project. The following example is valid for the byteDEVKIT with a byteENGINE IMX9x. For further information please visit our byteWIKI.



<https://bytwiki.readthedocs.io/en/latest/yocto/5.0/bytedevkit-imx93.html>

Link for byteENGINE STM32MP25x is coming soon.

> **Step 1:** Create the folder „yocto“ and change into directory using the following commands:

```
mkdir yocto
cd yocto
```

> **Step 2 :** Download all necessary repositories using repo:

```
repo init -u https://github.com/bytesatwork/bsp-platform-nxp.git -b scarthgap repo sync
```

> **Step 3:** When these commands are completed successfully, the following command will setup a Yocto Project environment for byteDEVKIT:

```
MACHINE=bytedevkit-imx93 DISTRO=poky-bytesatwork EULA=1 . setup-environment build
```

> **Step 4:** The final command builds a development image:

(this will last several hours, depending on the build machine)

```
bitbake bytesatwork-minimal-image
```

> **Step 5:** Create and write the SD-Card Image:

(replace sdX with SD-Card drive)

```
cd tmp/deploy/images/bytedevkit-imx93
xzcat bytesatwork-minimal-image-bytedevkit-imx93.wic.xz | dd of =/dev/sdX bs=1M
conv=fsync
```

## 3. Pinout functions

### 3.1. X4 MIPI DSI connector

| Con | Pin | Signal Name |
|-----|-----|-------------|
| X4  | 1   | NC          |
| X4  | 2   | LEDK        |
| X4  | 3   | NC          |
| X4  | 4   | LEDA        |
| X4  | 5   | NC          |
| X4  | 6   | VCI         |
| X4  | 7   | IOVCC       |
| X4  | 8   | TE          |
| X4  | 9   | RESET       |
| X4  | 10  | GND         |
| X4  | 11  | MIPI_D1P    |
| X4  | 12  | MIPI_D1N    |
| X4  | 13  | GND         |
| X4  | 14  | MIPI_CLP    |
| X4  | 15  | MIPI_CLN    |
| X4  | 16  | GND         |
| X4  | 17  | MIPI_D0P    |
| X4  | 18  | MIPI_D0N    |
| X4  | 19  | GND         |
| X4  | 20  | GND         |

## 3.2. X5 MIPI Touch Connector

| Con | Pin | Signal Name | Alternative Modes |               |               |              |             |               |               |
|-----|-----|-------------|-------------------|---------------|---------------|--------------|-------------|---------------|---------------|
|     |     |             | 1                 | 2             | 3             | 4            | 5           | 6             | 7             |
| X5  | 1   | GND         |                   |               |               |              |             |               |               |
| X5  | 2   | VDDIO       |                   |               |               |              |             |               |               |
| X5  | 3   | VDD         |                   |               |               |              |             |               |               |
| X5  | 4   | I2C1_SCL    | GPIO1_I002        | LPUART2_DCB_B | TPM2_CH2      | SAI1_RX_SYNC | LPI2C2_SCL  | I3C1_PUR      | I3C1_PUR_B    |
| X5  | 5   | I2C1_SDA    | GPIO1_I003        | LPUART2_RIN_B | TPM2_CH3      | SAI1_RX_BCLK | LPI2C2_SDA  |               |               |
| X5  | 6   | TOUCH_INT   | GPIO2_I023        | FLEXIO1_I023  | USDHC3_CMD    | TPM6_CH1     | LPI2C5_SCL  | SPDIF_OUT     | MMX_D_DA-TA19 |
| X5  | 7   | TOUCH_RESET | GPIO2_I011        | FLEXIO1_I011  | LPUART7_RTS_B | LPSP13_SCK   | TPM5_EXTCLK | MMX_C_DA-TA05 | MMX_D_DA-TA07 |
| X5  | 8   | GND         |                   |               |               |              |             |               |               |

## 3.3. X6 5-inch LVDS Display Connector

| Con | Pin | Signal Name |
|-----|-----|-------------|
| X6  | 1   | LEDA        |
| X6  | 2   | LEDA        |
| X6  | 3   | YU(NC)      |
| X6  | 4   | XL(NC)      |
| X6  | 5   | YD(NC)      |
| X6  | 6   | XR(NC)      |
| X6  | 7   | U/D/HDIR    |
| X6  | 8   | L/R/VDIR    |
| X6  | 9   | LED-        |
| X6  | 10  | LED-        |
| X6  | 11  | GND         |
| X6  | 12  | NC          |
| X6  | 13  | NC          |
| X6  | 14  | NC          |
| X6  | 15  | NC          |
| X6  | 16  | GND         |
| X6  | 17  | NC          |
| X6  | 18  | NC          |
| X6  | 19  | GND         |

| Con | Pin | Signal Name     |
|-----|-----|-----------------|
| X6  | 20  | OLDIO_A3P       |
| X6  | 21  | OLDIO_A3N       |
| X6  | 22  | GND             |
| X6  | 23  | OLDIO_CLK0P     |
| X6  | 24  | OLDIO_CLK0N     |
| X6  | 25  | GND             |
| X6  | 26  | OLDIO_A2N       |
| X6  | 27  | OLDIO_A2P       |
| X6  | 28  | GND             |
| X6  | 29  | OLDIO_A1N       |
| X6  | 30  | OLDIO_A1P       |
| X6  | 31  | GND             |
| X6  | 32  | OLDIO_A0N       |
| X6  | 33  | OLDIO_A0P       |
| X6  | 34  | GND             |
| X6  | 35  | DISPLAY1_ENABLE |
| X6  | 36  | DISPLAY1_RESET  |
| X6  | 37  | NC              |
| X6  | 38  | 3V3             |
| X6  | 39  | 3V3             |
| X6  | 40  | NC              |

## 3.4. X7 LVDS Touch connector

| Con | Pin | Signal Name | Alternative Modes |               |             |             |              |                  |          |
|-----|-----|-------------|-------------------|---------------|-------------|-------------|--------------|------------------|----------|
|     |     |             | 1                 | 2             | 3           | 4           | 5            | 6                | 7        |
| X7  | 1   | GND         |                   |               |             |             |              |                  |          |
| X7  | 2   | VDDIO       |                   |               |             |             |              |                  |          |
| X7  | 3   | VDD         |                   |               |             |             |              |                  |          |
| X7  | 4   | I2C1_SCL    | GPIO1_IO00        | LPUART2_DCB_B | TPM2_CH0    | LPI2C1_SCL  | I3C1_SCL     | LPI2C1_SCL       |          |
| X7  | 5   | I2C1_SDA    | GPIO1_IO01        | LPUART2_RIN_B | TPM2_CH1    | LPI2C1_SDA  | I3C1_SDA     |                  |          |
| X7  | 6   | TOUCH_INT   | GPIO2_IO20        | FLEXIO1_IO20  | LPSPi4_SOUT | LPSPi5_SOUT | TPM3_CH1     | SAI3_RX_DA- TA00 | PDM_BS00 |
| X7  | 7   | TOUCH_RESET | GPIO2_IO21        | LPSPi4_SCK    | LPSPi5_SCK  | TPM4_CH1    | SAI3_RX_BCLK | SAI3_TX_DA- TA00 | PDM_CLK  |
| X7  | 8   | GND         |                   |               |             |             |              |                  |          |

## 3.5. X3 Camera

| Con | Pin | Signal Name | Alternative Modes |   |   |   |   |   |   |
|-----|-----|-------------|-------------------|---|---|---|---|---|---|
|     |     |             | 1                 | 2 | 3 | 4 | 5 | 6 | 7 |
| X3  | 1   | GND         |                   |   |   |   |   |   |   |
| X3  | 2   | CSI0_RXN0   |                   |   |   |   |   |   |   |
| X3  | 3   | CSI0_RXP0   |                   |   |   |   |   |   |   |
| X3  | 4   | GND         |                   |   |   |   |   |   |   |
| X3  | 5   | CSI0_RXN1   |                   |   |   |   |   |   |   |
| X3  | 6   | CSI0_RXP1   |                   |   |   |   |   |   |   |
| X3  | 7   | GND         |                   |   |   |   |   |   |   |
| X3  | 8   | CSI0_RXCLKN |                   |   |   |   |   |   |   |
| X3  | 9   | CSI0_RXCLKP |                   |   |   |   |   |   |   |
| X3  | 10  | GND         |                   |   |   |   |   |   |   |
| X3  | 11  | NC          |                   |   |   |   |   |   |   |
| X3  | 12  | NC          |                   |   |   |   |   |   |   |
| X3  | 13  | GND         |                   |   |   |   |   |   |   |
| X3  | 14  | NC          |                   |   |   |   |   |   |   |
| X3  | 15  | NC          |                   |   |   |   |   |   |   |
| X3  | 16  | GND         |                   |   |   |   |   |   |   |
| X3  | 17  | CAMERA_nRST |                   |   |   |   |   |   |   |
| X3  | 18  | CAMERA_MCLK |                   |   |   |   |   |   |   |
| X3  | 19  | GND         |                   |   |   |   |   |   |   |
| X3  | 20  | NC          |                   |   |   |   |   |   |   |
| X3  | 21  | NC          |                   |   |   |   |   |   |   |
| X3  | 22  | 3.3V        |                   |   |   |   |   |   |   |

## 3.6. X12 60PIN Connector

| Con | Pin | Signal Name | OSM Name   | Alternative Modes |              |               |               |             |              |              |              |
|-----|-----|-------------|------------|-------------------|--------------|---------------|---------------|-------------|--------------|--------------|--------------|
|     |     |             |            | 1                 | 2            | 3             | 4             | 5           | 6            | 7            |              |
| X12 | 1   | 5V          |            |                   |              |               |               |             |              |              |              |
| X12 | 2   | 3V3         |            |                   |              |               |               |             |              |              |              |
| X12 | 3   | 1V8         |            |                   |              |               |               |             |              |              |              |
| X12 | 4   | CLK04       | PWM_2      | GPIO4_IO29        | FLEXIO2_IO29 | CCM_CLK04     |               |             |              |              |              |
| X12 | 5   | NVCC_GPIO   |            |                   |              |               |               |             |              |              |              |
| X12 | 6   | PWM3        | PWM_3      | GPIO2_IO29        | FLEXIO1_IO29 | LPI2C3_SCL    |               |             |              |              |              |
| X12 | 7   | GPIO.A0     | GPIO_A_0   | I2C2_EXP_IO00     |              |               |               |             |              |              |              |
| X12 | 8   | ADC.CH0     | ADC_0      | ADC_IN0           |              |               |               |             |              |              |              |
| X12 | 9   | GPIO.A1     | GPIO_A_1   | I2C2_EXP_IO01     |              |               |               |             |              |              |              |
| X12 | 10  | ADC.CH1     | ADC_1      | ADC_IN1           |              |               |               |             |              |              |              |
| X12 | 11  | GPIO.A2     | GPIO_A_2   | I2C2_EXP_IO02     |              |               |               |             |              |              |              |
| X12 | 12  | UART3.RXD   | UART_A_RX  | GPIO2_IO15        | FLEXIO1_IO15 | LPUART3_RX    | LPUART8_RTS_B | LPUART4_RX  | LPSPi8_SCK   | MMX_C_DATA7  | MMX_D_DATA11 |
| X12 | 13  | GPIO.A3     | GPIO_A_3   | I2C2_EXP_IO03     |              |               |               |             |              |              |              |
| X12 | 14  | UART3.TXD   | UART_A_TX  | GPIO2_IO14        | FLEXIO1_IO14 | LPUART3_TX    | LPUART8_CTS_B | LPUART4_TX  | LPSPi8_SOUT  | MMX_C_DATA6  | MMX_D_DATA10 |
| X12 | 15  | GPIO.A4     | GPIO_A_4   | I2C2_EXP_IO04     |              |               |               |             |              |              |              |
| X12 | 16  | UART3.RTS   | UART_A_RTS | GPIO2_IO17        | FLEXIO1_IO17 | LPUART3_RTS_B | LPUART4_RTS_B | LPSPi4_PCS1 | SAI3_MCLK    | MMX_C_DATA8  | MMX_D_DATA13 |
| X12 | 17  | GPIO.A5     | GPIO_A_5   | I2C2_EXP_IO05     |              |               |               |             |              |              |              |
| X12 | 18  | UART3.CTS   | UART_A_CTS | GPIO2_IO16        | FLEXIO1_IO16 | LPUART3_CTS_B | LPUART4_CTS_B | LPSPi4_PCS2 | SAI3_TX_BCLK | PDM_BS02     | MMX_D_DATA12 |
| X12 | 19  | GPIO.A6     | GPIO_A_6   | GPIO2_IO08        | FLEXIO1_IO08 | LPUART7_TX    | LPSPi3_PCS0   | TPM6_CH0    | MMX_C_DATA02 | MMX_D_DATA04 | LPI2C7_SDA   |
| X12 | 20  | UART5.RXD   | UART_B_RX  | GPIO2_IO01        | FLEXIO1_IO01 | LPUART5_RX    | LPSPi6_SIN    | LPI2C3_SCL  | LPI2C5_SCL   | MMX_C_DATA00 | MMX_D_DE     |
| X12 | 21  | GPIO.A7     | GPIO_A_7   | GPIO2_IO09        | FLEXIO1_IO09 | LPUART6_RTS_B | LPSPi3_SIN    | TPM3_EXTCLK | MMX_C_DATA03 | MMX_D_DATA05 | LPI2C7_SCL   |
| X12 | 22  | UART5.TXD   | UART_B_TX  | GPIO2_IO00        | FLEXIO1_IO00 | LPUART5_TX    | LPSPi6_PCS0   | LPI2C3_SDA  | LPI2C5_SDA   | MMX_C_CLK    | MMX_D_CLK    |



| Con | Pin | Signal Name   | OSM Name        | Alternative Modes |               |               |                   |                |              |              |              |
|-----|-----|---------------|-----------------|-------------------|---------------|---------------|-------------------|----------------|--------------|--------------|--------------|
|     |     |               |                 | 1                 | 2             | 3             | 4                 | 5              | 6            | 7            | 8            |
| X12 | 23  | GPIO.B0       | GPIO_B_0        | I2C2_EXP_I006     |               |               |                   |                |              |              |              |
| X12 | 24  | UART5.RTS     | UART_B_RTS      | GPIO2_I003        | FLEXIO1_I003  | LPUART5_RTS_B | LPSP16_SCK        | LPI2C4_SCL     | LPI2C6_SCL   | MMX_C_HSYNC  | MMX_D_HSYNC  |
| X12 | 25  | GPIO.B1       | GPIO_B_1        | I2C2_EXP_I007     |               |               |                   |                |              |              |              |
| X12 | 26  | UART5.CTS     | UART_B_CTS      | GPIO2_I002        | FLEXIO1_I002  | LPUART5_CTS_B | LPSP16_SOUT       | LPI2C4_SDA     | LPI2C6_SDA   | MMX_C_VSYNC  | MMX_D_VSYNC  |
| X12 | 27  | SAI1.RXD0     | I2S_A_DATA_IN   | GPIO1_I014        | LPUART2_DSR_B | LPSP11_SOUT   | SAI1_RX_DATA00    | SAI1_MCLK      | MQS1_RIGHT   |              |              |
| X12 | 28  | UART2.RXD     | UART_C_RX       | GPIO1_I06         | LPUART1_CTS_B | LPUART2_RX    | LPSP12_SOUT       | TPM1_CH2       | SAI1_MCLK    |              |              |
| X12 | 29  | SAI1.TXD0     | I2S_A_DATA_OUT  | GPIO1_I013        | LPUART2_RTS_B | LPUART1_DTR_B | LPSP11_SCK        | SAI1_TX_DATA00 | CAN1_TX      |              |              |
| X12 | 30  | UART2.TXD     | UART_C_TX       | GPIO1_I07         | LPUART1_RTS_B | LPUART2_TX    | LPSP12_SCK        | TPM1_CH3       |              |              |              |
| X12 | 31  | SAI1.TXFS     | I2S_LRCLK       | GPIO1_I011        | LPUART2_DTR_B | LPSP11_PCS0   | SAI1_TX_SYNC      | SAI1_TX_DATA01 | MQS1_LEFT    |              |              |
| X12 | 32  | UART8.RXD     | UART_D_RX       | GPIO2_I013        | FLEXIO1_I013  | LPUART8_RX    | LPSP18_SIN        | TPM4_CH2       | LPI2C8_SCL   | PDM_BS03     | MMX_D_DATA09 |
| X12 | 33  | SAI1.TXC      | I2S_BITCLK      | GPIO1_I012        | LPUART2_CTS_B | LPUART1_DSR_B | LPSP11_SIN        | SAI1_TX_BCLK   | CAN1_RX      |              |              |
| X12 | 34  | UART8.TXD     | UART_D_TX       | GPIO2_I012        | SAI3_RX_SYNC  | LPUART8_TX    | LPSP18_PCS0       | TPM3_CH2       | LPI2C8_SDA   | PDM_BS02     | MMX_D_DATA08 |
| X12 | 35  | SAI1.MCLK     | I2S_MCLK        | GPIO4_I028        | FLEXIO2_I028  | CCM_CLK03     |                   |                |              |              |              |
| X12 | 36  | I2C1.SCL      | I2C_A_SCL       | GPIO1_I000        | LPUART1_DCB_B | TPM2_CH0      | LPI2C1_SCL        | I3C1_SCL       |              |              |              |
| X12 | 37  | FLEXSPI1.SS   | SPI_A_CS0#      | GPIO3_I021        | FLEXIO1_I021  | USDHC3_CMD    | FLEXSPI1_A_SS0_B  |                |              |              |              |
| X12 | 38  | I2C1.SDA      | I2C_A_SDA       | GPIO1_I001        | LPUART1_RIN_B | TPM2_CH1      | LPI2C1_SDA        | I3C1_SDA       |              |              |              |
| X12 | 39  | FLEXSPI1.SCLK | SPI_A_SCK       | GPIO3_I020        | FLEXIO1_I020  | USDHC3_CLK    | FLEXSPI1_A_SCLK   |                |              |              |              |
| X12 | 40  | I2C2.SCL      | I2C_B_SCL       | GPIO1_I002        | LPUART2_DCB_B | TPM2_CH2      | SAI1_RX_SYNC      | LPI2C2_SCL     | I3C1_PUR     | I3C1_PUR_B   |              |
| X12 | 41  | FLEXSPI1.D0   | SPI_A_SDI_(I00) | GPIO3_I022        | FLEXIO1_I022  | USDHC3_DATA0  | FLEXSPI1_A_DATA00 |                |              |              |              |
| X12 | 42  | I2C2.SDA      | I2C_B_SDA       | GPIO1_I003        | LPUART2_RIN_B | TPM2_CH3      | SAI1_RX_BCLK      | LPI2C2_SDA     |              |              |              |
| X12 | 43  | FLEXSPI1.D1   | SPI_A_SDO_(I01) | GPIO3_I023        | FLEXIO1_I023  | USDHC3_DATA1  | FLEXSPI1_A_DATA01 |                |              |              |              |
| X12 | 44  | SD3.CLK       | SDIO_B_CLK      | GPIO2_I022        | FLEXIO1_I022  | USDHC3_CLK    | TPM5_CH1          | TPM6_EXTCLK    | LPI2C5_SDA   | SPDIF_IN     | MMX_D_DATA18 |
| X12 | 45  | FLEXSPI1.D2   | SPI_A_WP_(I02)  | GPIO3_I024        | FLEXIO1_I024  | USDHC3_DATA2  | FLEXSPI1_A_DATA02 |                |              |              |              |
| X12 | 46  | SD3.CMD       | SDIO_B_CMD      | GPIO2_I023        | FLEXIO1_I023  | USDHC3_CMD    | TPM6_CH1          | LPI2C5_SCL     | SPDIF_OUT    | MMX_D_DATA19 |              |
| X12 | 47  | FLEXSPI1.D3   | SPI_A_HOLD(I03) | GPIO3_I025        | FLEXIO1_I025  | USDHC3_DATA3  | FLEXSPI1_A_DATA03 |                |              |              |              |
| X12 | 48  | SD3.D0        | SDIO_B_D0       | GPIO2_I024        | FLEXIO1_I024  | LPSP16_PCS1   | USDHC3_DATA0      | TPM3_CH3       | MMX_D_DATA20 | JTAG_MUX_TDO |              |

| Con | Pin | Signal Name | OSM Name   | Alternative Modes |              |               |              |              |              |              |              |  |
|-----|-----|-------------|------------|-------------------|--------------|---------------|--------------|--------------|--------------|--------------|--------------|--|
|     |     |             |            | 1                 | 2            | 3             | 4            | 5            | 6            | 7            | 8            |  |
| X12 | 49  | SPI7.CS     | SPI_B_CS0# | GPI02_IO04        | FLEXIO1_IO04 | LPUART6_TX    | LPSPi7_PCS0  | TPM3_CH0     | MMX_D_DATA00 | LPI2C6_SDA   |              |  |
| X12 | 50  | SD3.D1      | SDIO_B_D1  | GPI02_IO25        | FLEXIO1_IO25 | LPSPi7_PCS1   | USDHC3_DATA1 | TPM4_CH3     | MMX_D_DATA21 | CAN2_TX      | JTAG_MUX_TCK |  |
| X12 | 51  | SPI7.SCK    | SPI_B_SCK  | GPI02_IO07        | FLEXIO1_IO07 | LPUART6_RTS_B | LPSPi3_PCS1  | LPSPi7_SCK   | MMX_C_DATA01 | MMX_D_DATA03 | LPI2C7_SCL   |  |
| X12 | 52  | SD3.D2      | SDIO_B_D2  | GPI02_IO26        | LPSPi8_PCS1  | USDHC3_DATA2  | TPM5_CH3     | MMX_D_DATA22 | SAI3_TX_SYNC | PDM_BS01     | JTAG_MUX_TDI |  |
| X12 | 53  | SPI7.SIN    | SPI_B_SDI  | GPI02_IO05        | FLEXIO1_IO05 | LPUART6_RX    | LPSPi7_SIN   | TPM4_CH0     | MMX_D_DATA01 | LPI2C6_SCL   | PDM_BS00     |  |
| X12 | 54  | SD3.D3      | SDIO_B_D3  | GPI02_IO27        | FLEXIO1_IO27 | LPSPi5_PCS1   | USDHC3_DATA3 | TPM6_CH3     | MMX_D_DATA23 | CAN2_RX      | JTAG_MUX_TMS |  |
| X12 | 55  | SPI7.SOUT   | SPI_B_SDO  | GPI02_IO06        | FLEXIO1_IO06 | LPUART6_CTS_B | LPSPi7_SOUT  | TPM5_CH0     | MMX_D_DATA02 | LPI2C7_SDA   | PDM_BS01     |  |
| X12 | 56  | CAN2.TXD    | CAN_B_TX   | GPI03_IO28        | FLEXIO2_IO30 | LPUART5_RX    | CAN2_TX      | MQS2_LEFT    | JTAG_MUX_TDI |              |              |  |
| X12 | 57  | CAN1.TXD    | CAN_A_TX   | GPI01_IO08        | PDM_CLK      | CAN1_TX       | MQS1_LEFT    | LPTMR1_ALT1  |              |              |              |  |
| X12 | 58  | CAN2.RXD    | CAN_B_RX   | GPI03_IO31        | FLEXIO1_IO31 | LPUART5_TX    | CAN2_RX      | MQS2_RIGHT   | JTAG_MUX_TDO |              |              |  |
| X12 | 59  | CAN1.RXD    | CAN_A_RX   | GPI01_IO09        | LPSPi1_PCS1  | TPM1_EXTCLK   | PDM_BS00     | CAN1_RX      | MQS1_RIGHT   | LPTMR1_ALT2  |              |  |
| X12 | 60  | GND         | GND        |                   |              |               |              |              |              |              |              |  |

## 4. Connectors

### Power

|              |              |
|--------------|--------------|
| <b>X13.1</b> | 8-30 V       |
| <b>X13.2</b> | Ground (GND) |


### SL1: Console

|              |           |
|--------------|-----------|
| <b>SL1.1</b> | GND       |
| <b>SL1.4</b> | UART1-RXD |
| <b>SL1.5</b> | UART1-TXD |

**Do not connect other pins**

### SL2: JTAG/SWD (ARM 10 Pin connector)

|           |            |
|-----------|------------|
| <b>1</b>  | VTref      |
| <b>2</b>  | SWDIO/TMS  |
| <b>3</b>  | GND        |
| <b>4</b>  | SWCLK/TCK  |
| <b>5</b>  | GND        |
| <b>6</b>  | SWO/TDO    |
| <b>7</b>  | ---        |
| <b>8</b>  | TDI        |
| <b>9</b>  | NC - TRSTN |
| <b>10</b> | nRESET     |



### LEDs

|             |                         |
|-------------|-------------------------|
| <b>LED1</b> | Green: Powersupply 3.3V |
|-------------|-------------------------|

### Buttons

|                        |                     |
|------------------------|---------------------|
| <b>Power Button</b>    | TA1 ON / OFF to SOC |
| <b>Reset Button</b>    | System Reset        |
| <b>Recovery Button</b> | Force to USB Boot   |

## 5. Boot modes

The OSM Standard implements two BOOT Pins: BOOT\_SEL0# and BOOT\_SEL1#.

BOOT\_MODE2 and BOOT\_MODE3 are connected to Vendor Defined Pins.

While BOOT\_MODE0 and BOOT\_MODE1 are automatically disconnected on the byteENGINE after power on reset, the logic for BOOT\_MODE2 and BOOT\_MODE3 must be handled on the baseboard separately. The boot sequence can be redefined with OTP writing.

### 5.1. byteENGINE IMX9x

| Bootmode Pin | IMX9x PAD | OSM PAD             | Note                                                      |
|--------------|-----------|---------------------|-----------------------------------------------------------|
| BOOT_MODE0   | UART1_TXD | (U19) BOOT_SEL0#    | automatically disconnected after Boot                     |
| BOOT_MODE1   | UART2_TXD | (R18) BOOT_SEL1#    | automatically disconnected after Boot                     |
| BOOT_MODE2   | SAI1_TXFS | (D6) Vendor Defined | Vendor defined pins, disconnect logic needed on baseboard |
| BOOT_MODE3   | SAI1_TXD0 | (D7) Vendor Defined | Vendor defined pins, disconnect logic needed on baseboard |

| CPU        | BOOD_MODE (3:0) | BOOT Source                     |
|------------|-----------------|---------------------------------|
| Cortex-A55 | 0000            | Boot from internal Fuses        |
|            | 0001            | Serial Download (USB1)          |
|            | 0010            | USDHC1 8-bit eMMC 5.1           |
|            | 0011            | USDHC2 4-bit SD 3.0             |
|            | 0100            | FlexSPI Serial NOR              |
|            | 0101            | FlexSPI Serial NAND 2K          |
| Cortex-M33 | 1000            | LPB: Boot From Internal Fuses   |
|            | 1001            | LPB: Serial Downloader (USB1)   |
|            | 1010            | LPB: USDHC1 8-bit 1.8V eMMC 5.1 |
|            | 1011            | LPB: USDHC2 4-bit SD 3.0        |
|            | 1100            | LPB: FlexSPI Serial NOR         |
|            | 1101            | LPB: FlexSPI Serial NAND 2K     |

## 5.2. byteENGINE STM32MP2


| Bootmode Pin | STM32MP2 PAD | OSM PAD | Note                                                      |
|--------------|--------------|---------|-----------------------------------------------------------|
| BOOT_MODE0   | T2           | U19     | Automatically disconnected after Boot                     |
| BOOT_MODE1   | P3           | R18     | Automatically disconnected after Boot                     |
| BOOT_MODE2   | T3           | D6      | Vendor defined pins, disconnect logic needed on baseboard |
| BOOT_MODE3   | R3           | D7      | Vendor defined pins, disconnect logic needed on baseboard |

| CPU              | BOOT_MODE [3:0] | BOOT Source      |
|------------------|-----------------|------------------|
| Cortex A35 + M33 | 0000            | UART and USB     |
| Cortex A35       | 0001            | SD-Card          |
|                  | 0010            | eMMC             |
|                  | 0011            | Development boot |
|                  | 0100            | Serial NOR       |
|                  | 0101            | Serial NAND      |
|                  | 0110            | SLC NAND         |
| Cortex M33       | 0111            | SD-Card          |
|                  | 1000            | e-MMC            |
|                  | 1001            | -                |
|                  | 1010            | -                |
| Cortex M33       | 1011            | Serial NOR       |
| Cortex A35 + M33 | 1100            | Development boot |
|                  | 1101            | -                |
|                  | 1110            | -                |
| Cortex A35 + M33 | 1111            | UART and USB     |


## 6. Mechanical dimensions byteDEVKIT OSM-S

The following illustration shows all important dimensions for mounting and installation of the byteDEVKIT OSM-S.


> All dimensions are indicated in millimetres (mm)



## 6.1. Mechanical dimensions of byteENGINE IMX9x



## 6.2. Mechanical dimensions of byteENGINE STM32MP2



## 7. Ordering info

The Order Code allows customers to easily recognize the detailed specification of the ordered SOM. Please refer to chapter [Decision guidance byteDEVKIT OSM-S](#) for further information.

### byte[KIT]-[CPU]-[SPEED]-[RAM]-[FLASH]-[temp-range]-[revision]-[display]

|              |                   |                                                                       |
|--------------|-------------------|-----------------------------------------------------------------------|
| [KIT]        | Display Option    | DEVKIT: With Display<br>STARTKIT: Without Display                     |
| [CPU]        | CPU Type          | Comprehensive, see <a href="#">Decision guidance byteDEVKIT OSM-S</a> |
| [SPEED]      | Clock speed       | 800 MHz / 900 MHz / 1.2 GHz / 1.4 GHz / 1.5 GHz / 1.7 GHz             |
| [RAM]        | RAM size          | 512 / 768 / 1024 / 1536 / 2048 MB                                     |
| [FLASH]      | eMMC flash size   | 8 / 16 / 32 / 64 / 128 GB                                             |
| [temp-range] | Temperature range | [C] Consumer 0° to +85° C<br>[I] Industrial -40°C to +85 °C           |
| [revision]   | Revision          | 1.0                                                                   |
| [display]    | Display Option    | LVDS or MIPI (optional)                                               |



## 8. References byteDEVKIT OSM-S



### NOTICE

Files can only be downloaded with login credentials. Please request your download credentials via [support@bytesatwork.ch](mailto:support@bytesatwork.ch) or contact your sales representative.



### Links

> bytewiki::

<https://bytewiki.readthedocs.io/en/latest/vocto/5.0/bytedevkit-imx93.html>

Link for byteENGINE STM32MP25x is coming soon.

> bytesatwork on github:

<https://github.com/bytesatwork>

> byteDEVKIT OSM-S Schematic V1.0:

[byteDEVKIT OSM-S Schematic V1.0](#)

> Detailed Pinout List:

[Detailed Pinout List](#)



# Contact Information



## Address

bytesatwork  
Technoparkstrasse 7  
CH-8406 Winterthur  
Switzerland



## Phone

Phone: +41 52 213 79 79



## Email

[support@bytesatwork.ch](mailto:support@bytesatwork.ch)



## Product Information

[www.bytesatwork.io](http://www.bytesatwork.io)



## Help

[bytewiki.readthedocs.io](http://bytewiki.readthedocs.io)